

Washing Machine Outlet Box - Dual Drain

1. Determine water supply and drain location. Invert box if necessary.
2. Remove frame by pulling from inside the box.
3. Pressure test for leaks by connecting water supply.
4. Remove appropriate drain test cap by carefully knocking out with screwdriver and hammer.
5. Install and test for leaks before adding wall finishing and replacing frame.

